





DELABIE - DE710501, DE710500

SOAP DISH

DELABIE

GB Wall-mounted soap dish



- ① Ensure soap dish is level. ② Fix support in place: ensure screws and rawl plugs are suitable for wall type. ③ Clip soap dish onto support. ④ Tighten grub screw using a 3mm Allen key.